

FORD KIT - INDEX FILE					
SL.NO	PART NO	VEHICLE	OE REF NO	ENGINE MODEL	DESCRIPTION
1	S-FM-FS-0001-4	Ford tractor	F361134	Ford 401 BSD666 Naturally Aspirated Diesel Engine (1/68 - 9/76)	GASKET FULL SET
				Tractors: 8000, 8200 (1/68 - 9/72), 8400 (1/71 - 9/72), 8600 (10/72 - 7/76)	
		Excavators		Excavators: H48 Richier (1/74 - 9/76)	
		Wheel Loaders		Wheel Loaders: A64 (1/74 - 9/76)	
2	S-FM-FS-0002-4	Ford tractor	F361135	Ford 401,78	GASKET FULL SET
3	S-FM-FS-0003-4	Ford tractor	F361136	Ford 401 Diesel Engine	GASKET FULL SET
				Ford 7810, 7910, 8000, 8210, 8530, 8600, 8700, TW5, TW10	
				Ford Industrial A64 Diesel	
				Ford 401 turbo Diesel Engine	
				Ford 8630, 8730, 8830, 9000, 9600, 9700, TW15, TW20, TW25, TW30, TW35	
				Ford Industrial A66 Diesel	
4	S-FM-HS-0004-4	Ford	F361347	HEAD GASKET SET	GASKET TOP SET
5	S-FM-HS-0005-4	Ford	F361272	Ford-233,256,267,61	GASKET TOP SET
6	S-FM-HS-0006-4	Ford	F361271	FordT-188,17,183,192,021,61	GASKET TOP SET
7	S-FM-HS-0007-4	Ford	F361242	Ford- 158,175,183,192,021,61	GASKET TOP SET
8	S-FM-HS-0008-4	Ford	F361139	Ford 192 Diesel Engine	GASKET BOTTOM SET
				Ford 3230, 3430 Diesel	
				Ford Industrial 345C, 445C Diesel	
				Ford 201 Diesel Engine	
				Ford 3930, 4130, 4630 Diesel	
				Ford Industrial 345D, 445D, 455C, 455D, 545C, 545D, 555, L783, L783 Deluxe Diesel from 2/90	
9	S-FM-HS-0009-4	Ford	F361115	Ford-236,256,268	GASKET BOTTOM SET
10	S-FM-HS-0010-4	Ford	F361114	CONVERSION SET	

11	S-FM-HS-0011-4	Ford	F361142	CONVERSION SET	GASKET BOTTOM SET
12	S-FM-BS-0012-4	Ford	F361172	<u>Genesis 401 Diesel Engine</u>	GASKET BOTTOM SET
				Ford 7810S, 7840	
				<u>Genesis 456 Diesel Engine</u>	
				Ford 8010, 8240	
13	S-FM-BS-0013-4	Ford	F361148	Ford 8340	GASKET BOTTOM SET
				Genesis 268 Diesel Engine	
				Ford 5610S, 5640	
				Ford Industrial 555E, 655D Diesel	
				Genesis 304 Diesel Engine	
				Ford 6610S, 6640	
				Ford Industrial 655E Diesel	
				<u>Genesis 304 Turbo Diesel Engine</u>	
Ford 7010, 7610S, 7740					
14	S-FM-HG-0014-4	Ford	82845201	Ford Industrial 575E, 675E Diesel	HEAD GASKET
				Used in models:4400, 3500, 550, 555, 3400, 535, 4410, 420, 3550, 335, 4140, 4610SU, 515, 4500, 2600R, 3910V, 5340, 3150, 531, 2100, 3600, 3100, 6600, 4110V, 334, 2300, 2310, 4600SU, 3000-SERIES, 3110, 3910R, 4330, 6600C, 4600O, 3910N, 2910, 3055, 4200, 3610, 7000-SERIES, 2120, 3300, 2610, 2610V, 3610NO, 4340, 3910H, 3610V, 3600R, 4000-SERIES, 3330, 5190, 530A, 5200, 3600N, 230A, 3190, 5000-SERIES, 2600V, 4610O, 4110O, 4610N, 2110, 3600NO, 234, 6600O, 3310, 4190, 4110N, 7200, 4610NO, 5100, 4600NO, 4110NO, 4610V, 2600N, 3120, 3600V, 7100, 2000-SERIES, 2150, 2810	
				Used in models:5500-SERIES, 4400, 3500, 5550-SERIES, 3400, 535, 4410, 420, 3550, 335, 4140, 515, 4500, 2600R, 5340, 3150, 531, 2100, 3600, 3100, 6600, 2300, 2310, 4600SU, 3000-SERIES, 4330, 6600C, 4600O, 3055, 4200, 2120, 4340, 3600R, 4000-SERIES, 3330, 5190, 5200, 3600N, 5000-SERIES, 2600V, 4100, 2110, 3600NO, 6600O, 4190, 5100, 4600NO, 2600N, 3120, 3600V, 2000-SERIES, 2150	
				Used in models:5500-SERIES, 4400, 3500, 5550-SERIES, 3400, 535, 4410, 420, 3550, 335, 4140, 515, 4500, 2600R, 5340, 3150, 531, 2100, 3600, 3100, 6600, 2300, 2310, 4600SU, 3000-SERIES, 4330, 6600C, 4600O, 3055, 4200, 2120, 4340, 3600R, 4000-SERIES, 3330, 5190, 5200, 3600N, 5000-SERIES, 2600V, 4100, 2110, 3600NO, 6600O, 4190, 5100, 4600NO, 2600N, 3120, 3600V, 2000-SERIES, 2150	
				Used in models:5500-SERIES, 4400, 3500, 5550-SERIES, 3400, 535, 4410, 420, 3550, 335, 4140, 515, 4500, 2600R, 5340, 3150, 531, 2100, 3600, 3100, 6600, 2300, 2310, 4600SU, 3000-SERIES, 4330, 6600C, 4600O, 3055, 4200, 2120, 4340, 3600R, 4000-SERIES, 3330, 5190, 5200, 3600N, 5000-SERIES, 2600V, 4100, 2110, 3600NO, 6600O, 4190, 5100, 4600NO, 2600N, 3120, 3600V, 2000-SERIES, 2150	
				Used in models:5500-SERIES, 4400, 3500, 5550-SERIES, 3400, 535, 4410, 420, 3550, 335, 4140, 515, 4500, 2600R, 5340, 3150, 531, 2100, 3600, 3100, 6600, 2300, 2310, 4600SU, 3000-SERIES, 4330, 6600C, 4600O, 3055, 4200, 2120, 4340, 3600R, 4000-SERIES, 3330, 5190, 5200, 3600N, 5000-SERIES, 2600V, 4100, 2110, 3600NO, 6600O, 4190, 5100, 4600NO, 2600N, 3120, 3600V, 2000-SERIES, 2150	
				Used in models:5500-SERIES, 4400, 3500, 5550-SERIES, 3400, 535, 4410, 420, 3550, 335, 4140, 515, 4500, 2600R, 5340, 3150, 531, 2100, 3600, 3100, 6600, 2300, 2310, 4600SU, 3000-SERIES, 4330, 6600C, 4600O, 3055, 4200, 2120, 4340, 3600R, 4000-SERIES, 3330, 5190, 5200, 3600N, 5000-SERIES, 2600V, 4100, 2110, 3600NO, 6600O, 4190, 5100, 4600NO, 2600N, 3120, 3600V, 2000-SERIES, 2150	
				Used in models:5500-SERIES, 4400, 3500, 5550-SERIES, 3400, 535, 4410, 420, 3550, 335, 4140, 515, 4500, 2600R, 5340, 3150, 531, 2100, 3600, 3100, 6600, 2300, 2310, 4600SU, 3000-SERIES, 4330, 6600C, 4600O, 3055, 4200, 2120, 4340, 3600R, 4000-SERIES, 3330, 5190, 5200, 3600N, 5000-SERIES, 2600V, 4100, 2110, 3600NO, 6600O, 4190, 5100, 4600NO, 2600N, 3120, 3600V, 2000-SERIES, 2150	
				Used in models:5500-SERIES, 4400, 3500, 5550-SERIES, 3400, 535, 4410, 420, 3550, 335, 4140, 515, 4500, 2600R, 5340, 3150, 531, 2100, 3600, 3100, 6600, 2300, 2310, 4600SU, 3000-SERIES, 4330, 6600C, 4600O, 3055, 4200, 2120, 4340, 3600R, 4000-SERIES, 3330, 5190, 5200, 3600N, 5000-SERIES, 2600V, 4100, 2110, 3600NO, 6600O, 4190, 5100, 4600NO, 2600N, 3120, 3600V, 2000-SERIES, 2150	
				Used in models:5500-SERIES, 4400, 3500, 5550-SERIES, 3400, 535, 4410, 420, 3550, 335, 4140, 515, 4500, 2600R, 5340, 3150, 531, 2100, 3600, 3100, 6600, 2300, 2310, 4600SU, 3000-SERIES, 4330, 6600C, 4600O, 3055, 4200, 2120, 4340, 3600R, 4000-SERIES, 3330, 5190, 5200, 3600N, 5000-SERIES, 2600V, 4100, 2110, 3600NO, 6600O, 4190, 5100, 4600NO, 2600N, 3120, 3600V, 2000-SERIES, 2150	

16	S-FM-HG-0016-4	Ford	82845203	Used in models:5500-SERIES, 4400, 3500, 5550-SERIES, 3400, 535, 4410, 3550, 4140, 4500, 2600R, 5340, 3150, 531, 2100, 3600, 3100, 7600C, 6600, 2300, 2310, 4600SU, 3000-SERIES, 3110, 4330, 6600C, 4600O, 3055, 4200, 7000-SERIES, 2120, 3300, 4340, 3600R, 6700, 4000-SERIES, 3330, 5190, 7700, 3900, 5200, 3600N, 3190, 5000-SERIES, 2600V, 4100, 5600, 2110, 3600NO, 6600O, 3310, 5700, 4190, 7200, 5100, 4600NO, 2600N, 3120, 3600V, 7100, 2000-SERIES, 2150	HEAD GASKET
17	S-FM-HG-0017-4	Ford	82845222	Used in models:340, 540A, 445A, 535, 420, 545A, 450, 540B, 335, 4610SU, 532, 515, 2600R, 3910V, 531, 3600, 7600C, 6600, 4110V, 334, 4600SU, 3910R, 6600C, 4600O, 3910N, 2910, 3610, 2610, 2610V, 3610NO, 3910H, 3610V, 231, 3600R, 6700, 530A, 333, 7700, 3900, 3600N, 230A, 2600V, 4610O, 5600, 4110O, 4610N, 3600NO, 2310, 234, 6600O, 233, 5700, 4110N, 4610NO, 4600NO, 4110NO, 4610V, 2600N, 3600V, 2810	HEAD GASKET
18	S-FM-HG-0018-4	Ford	82855144	Used in models:A64, A66, TW20, 8000-SERIES, 9200, TW10, TW30, 9000-SERIES, 8600, 9600, 8700, 8200, 9700	HEAD GASKET
19	S-FM-HG-0019-4	Ford	87800517	Used in models:575D, 675E, 555D, 655E, 4400, 755B, 3500, A625, 655A, 3400, 555C, 535, 555E, 6500, 4410, 575E, 750, 655C, 655D, 675D, 3550, 4140, 7500, 755A, 4500, LX985, LS190, 1118, HW320, 2550, HW300, 2450, 7610S, 2600R, 5340, 3150, 531, 2100, 3600, TB90, 3100, 7600C, 5610, 6600, 6640, 2300, 2310, 4600SU, 3000-SERIES, 6810S, 3110, 4330, 6600C, TB100, 4600O, 4830, 6640O, 7010, 3055, TB110, 4200, 7610O, 7000-SERIES, 2120, 3300, 5610S, 6710, 4340, TS100, TS110, 6410, 3600R, 6700, 4000-SERIES, 3330, 5190, 5900, 7700, 3900, 6610O, 5200, 3600N, 7740O, 5640, 3190, 5000-SERIES, 2600V, 6610S, 4100, 5600, 2110, 3600NO, 5110, TB120, 6600O, 5030, 3310, 5030O, 5700, 7710, 4190, 4830O, 7200, 5100, 4830N, 7410, 4600NO, TS90, 2600N, 3120, 3600V, 7100, 2000-SERIES, 2150	HEAD GASKET
20	S-FM-HG-0020-4	Ford	87801653	CASE , John Deere	HEAD GASKET